

| Designation | Description | Coordinates | Reference |
|--------------------|---|--------------------|------------------|
| <u>A1</u> | Instrument cluster | 10L | PE54.30 |
| <u>A1p8</u> | Electronic speedometer | 9L | |
| <u>A2</u> | Radio | 8A | PE82.60 |
| <u>A2/4</u> | Radio control module | 8A | |
| <u>L2</u> | Transmission inductive speed sensor | 10A | |
| <u>N3</u> | Injection system control module | 2A | |
| <u>N4/1</u> | EA/CC/ISC control module | 5A | |
| <u>N4/2</u> | CC control module (with reference resistor) | 6A | |
| <u>N10/2</u> | Combination relay module (turn signal with trailer coupling, rear window defroster, wiper motor, ATA) | 7L | |
| <u>N15/1</u> | Transmission control module (TCM) (5-speed automatic) | 3A | |
| <u>N22</u> | AAC pushbutton control module | 2L | |
| <u>N52</u> | Power soft top control module | 7A | |
| <u>X18</u> | Interior/taillamp harness connector (12-pole) | 7E | B.1/4 |
| <u>X26/12</u> | Interior/transmission connector | 9E | B.1/6 B.1/22 |
| <u>X30/1</u> | Multi-function connector block | 1E | B.1/5 |
| <u>X85/2</u> | Heater/interior connector (12-pole) | 1H | B.1/5 |