

Designation	Description	Coordinates	Reference
<u>N3/4</u>	HFM-SFI control module	1A	B.2/2
<u>N4/1</u>	EA/CC/ISC control module	7L	
<u>N15/1</u>	Transmission control module (TCM) (5-speed automatic)	4L	
<u>N30/1</u>	ABS/ASR control module	5L	
<u>N47-1</u>	ASR/SPS control module	5L	PE42.40
<u>N64</u>	RCL control module	6A	
<u>N59/1</u>	Diagnostic module (OBD II)	2L	