

Designation	Description	Coordinates	Reference
<u>A1</u>	Instrument cluster	7L	PE54.30
<u>A1e26</u>	"CHECK ENGINE" MIL	8L	
<u>K11/2</u>	Overvoltage protection relay module (87E/87L/30a, 9-pole) (Series K1/1)	6A	
<u>N15/1</u>	Transmission control module (TCM) (5-speed automatic)	4A	
<u>N16/1</u>	Base module (BM)	2L	
<u>N30/2</u>	ASD control module	2A	
<u>N49</u>	Steering angle sensor	11L	
<u>N49x1</u>	Steering angle sensor connector	11K	
<u>N51</u>	ADS suspension control module	9L	
<u>N59/1</u>	Diagnostic module (OBD II)	3L	
<u>S9/1</u>	Stop lamp switch (4-pole)	6L	PE42.40
<u>S16/9</u>	Transmission range "D" contact switch (5-speed automatic transmission)	3A	
<u>S45/1</u>	Comfort/sport switch (ADS)	12L	
<u>X4/10</u>	Terminal block (circuit 30/30Ü/61e/87L) (6-pole)	6E	B.1/1
<u>X30/1</u>	Multi-function connector block	5H	B.1/5
<u>X33/6</u>	ADS connector (front/rear suspension) (8-pole)	11H	B.1/7 B.1/22
<u>X95/4</u>	Cockpit /diagnostic module (OBD II) connector	7H	
<u>Y27/6</u>	Purge flow switchover valve	4L	