

Designation	Description	Coordinates	Reference
<u>F1</u>	Fuse and relay box	2L 13L 19L	B.4
<u>F1f4</u>	Fuse 4	2K	
<u>F1f8</u>	Fuse 8	13K 19K	
<u>H7</u>	Automatic dimming inside rearview mirror (ADM)	18L	
<u>M21/1</u>	Electrically adjustable and heated left outside rearview mirror	10L	
<u>M21/1m1</u>	Mirror adjustment motor (up/down)	10K	
<u>M21/1m2</u>	Mirror adjustment motor (in/out)	10K	
<u>M21/1r1</u>	Mirror heater	11K	
<u>M21/2</u>	Electrically adjustable and heated right outside rearview mirror	6L	
<u>M21/2m1</u>	Mirror adjustment motor (up/down)	5K	
<u>M21/2m2</u>	Mirror adjustment motor (in/out)	5K	
<u>M21/2r1</u>	Mirror heater	7K	
<u>N32/1</u>	Left front ESA control module (with memory)	3L	
<u>N32/9</u>	MSC control module (with memory)	4A 12A 20A 26A	
<u>S50</u>	Outside/inside mirror control switch	26L	
<u>S50s1</u>	Vertical mirror adjustment (up/down)	28L	
<u>S50s2</u>	Horizontal mirror adjustment (in/out)	24L	
<u>S50s3</u>	Left/right outside mirror/inside mirror	28J	
<u>W1</u>	Main ground (behind instrument cluster)	3E	
<u>W12</u>	Ground (center console)	14H 20H	
<u>X18/3</u>	Interior/taillamp harness connector (8-pole)	1H	B.1/4
<u>X30</u>	Accessory equipment connector block (5-pole)	16L 22L	B.1/2
<u>X64/6</u>	ESC connector (2-pole)	1E	B.1/4
<u>Z3/16</u>	Circuit 15 connector sleeve (from accessory equipment connector block)	21G	
<u>Z6/6</u>	Ground connector sleeve (feed from accessory equipment connector block, circuit 31)	16G 22G	